

Rackmount DC Battery Enclosure



{jatabs type="content" position="top" width="650" heightTabs="30" height="850" mousetype="click" animType="animMoveHor" skipAnim="false" duration=1000 } [tab title="Products"]

Model #	Battery Type	Amphours
RBE Series	12 and 24	8, 16, 24, 32

[/tab] [tab title="Overview"]

RBE Rack Battery Enclosure allows mounting of up to four 8AH sized batteries in a rack application. Designed to fit neatly into standard 19" equipment racks, the streamlined cabinetry and exceptional features combine to significantly reduce installation and service costs.

Features include removable terminal strips for field wiring, flexible wiring configuration for one to four battery outputs, and a 16 gauge steel 2U rack mount or wall mount chassis.

Product highlights

- Four individual battery outputs for flexibility in configuration of one to four battery sets
- Internal bracket to secure batteries in the rack (batteries not included)
- Self-resetting PTC overcurrent protection

Reliability and Safety

- RoHS Compliant
- Lifetime warranty

[Product Warranty](#)

[/tab] [tab title="Technical Documents"]

Model #	Datasheet	Install Manual	CAD Files
---------	-----------	----------------	-----------

RBE Series

[DS](#) [IM](#) [CAD](#) [AG](#)

[/tab] [tab title="Support"]

[Troubleshooting Guide](#)

[Factory Contact](#)

[Business Contact](#)

[FPO Troubleshooting](#) [Email Customer Service](#) [Accounting Office](#)

[Accessory Troubleshooting](#) [Email Technical Department](#) [Area Sales Representatives](#)

[/tab] [tab title="Tools & Software"] **Tools & Software**

Excel spreadsheets designed by the LifeSafety Power technical department to aid the installer in required calculations and example configurations of LifeSafety Power equipment when used in commonly found system applications.

Calculators / Software

[PowerCom-USB Download](#)

[Ohms Law Calculator](#)

[Battery Size Calculator](#)

[Battery Capacity Calculator](#)

[Wire Size Calculator](#)

[Voltage Drop Calculator](#)

[FlexCalculator Suite](#)

Application Notes

[AN20_LSP Monitoring Guide](#)

[/tab] {/jatabs}